


MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPU 04
	XPU 06
	XPU 08
	XPU 10
	XPU 12
	XPU 16

MODEL (ΦD1 - ΦD2) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD1 ΦD2	XPG 6X4
	XPG 8X4
	XPG 8X6
	XPG 10X6
	XPG 10X8
	XPG 12X10
	XPG 16X12

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPV 04
	XPV 06
	XPV 08
	XPV 10
	XPV 12
	XPV 16

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPE 04
	XPE 06
	XPE 08
	XPE 10
	XPE 12
	XPE 16

MODEL (ΦD1 - ΦD2) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD1 ΦD2	XPEG 4X6X4
	XPEG 6X8X6
	XPEG 8X10X8
	XPEG 10X12X10
	XPEG 12X16X12

MODEL (ΦD1 - ΦD2) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD1 ΦD2	XPGE 6X4X6
	XPGE 8X6X8
	XPGE 10X8X10
	XPGE 12X10X12
	XPGE 16X12X16

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPY 04
	XPY 06
	XPY 08
	XPY 10
	XPY 12
	XPY 16

MODEL (ΦD1 - ΦD2) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD1 ΦD2	XPW 4X6X4
	XPW 6X8X6
	XPW 6X10X6
	XPW 8X10X8
	XPW 10X12X10

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPZA 04
	XPZA 06
	XPZA 08
	XPZA 10
	XPZA 12

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPK 04
	XPK 06
	XPK 08
	XPK 10
	XPK 12

MODEL (ΦD) (Loại)	Tube (Metric) - Ống (hệ mét)
 ΦD	XPM 04
	XPM 06
	XPM 08
	XPM 10
	XPM 12